


## OPERATION & SAFETY MANUAL



**! WARNING**

*These instructions are for your personal safety. Always ensure that you have read and understood these instructions before using the machinery.*  
**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

# TABLE OF CONTENTS

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

TOPIC	PAGE
General Machine Safety Information	3
Storage & Disposal	4
CE Declaration of Conformity	5
General Information	6
Operating Instructions	7
Warranty Policy & Procedure	9

To watch practical demonstration videos, take a course, or to download an electronic copy of these Instructions, please visit [www.picoteinstitute.com](http://www.picoteinstitute.com). Please note that videos and courses are not intended as a replacement or alternative to this operating and safety manual, but only as an additional learning tool.

# GENERAL MACHINE SAFETY INFORMATION

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

## **⚠️ WARNING**

*This section contains important safety information. Failure to comply could result in serious injury.*

**Always read all safety warnings and instructions.** Failure to follow warnings and instructions may result in serious injury.

## **Personal Protective Equipment (PPE)**

Always use Personal Protective Equipment including suitable protective clothing, footwear, plus:



Suitable eye protection to protect against sewage, chemicals or dust from irritating eyes.



Suitable cut-resistant gloves to help prevent any hand injuries. Any open injuries or skin irritations should always be covered to avoid contact with sewage, chemicals or dust.

1. **Always wear eye protection as well as cut-resistant gloves.**

Other personal protective equipment, such as dust mask, gloves and overalls should be worn when necessary.

**Always wear appropriate personal protective equipment.**

2. **Before each use** inspect the Liner Compressor carefully for any potential break or damage.

**Change damaged parts immediately.**

3. Only use this tool for its intended use with the accessories and spare parts offered by the Picote Solutions. Accessories and spare parts should only be used in the manner intended and as described by Picote Solutions.

# STORAGE & DISPOSAL

**SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE**

## **STORAGE**

It is recommended that the Liner Compressor 3.0 is stored indoors to protect it from rain and sunlight and also in a constant ambient temperature.

## **DISPOSAL**

The wire and screws can be recycled in metal waste collection points. The plastic casing can be disposed of as plastic waste.

**Always follow your local waste handling rules and regulations.**



# CE DECLARATION OF CONFORMITY

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

We Picote Solutions Oy Ltd as the responsible manufacturer, declare that the following Picote Solutions Oy Ltd Cured-in-place pipe lining tool:

**Picote Liner Compressor**

**Model No: Picote Liner Compressor 3.0**

are of series production and

**Conform to the following EU Directive:**

2006/42/EY

And is manufactured in accordance with the following standards or standardised documents:


SFS-EN ISO 12100

SFS-EN ISO/TR 14121-2:2013

The technical documentation is kept by our authorised representative in Europe who is:

Picote Solutions Oy Ltd, Pienteollisuustie 24  
06450 Porvoo, Finland

23th November 2021




Katja Lindy-Wilkinson  
C.E.O.

Picote Solutions Oy Ltd  
Pienteollisuustie 24, 06450 Porvoo, Finland

# GENERAL INFORMATION

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE



# OPERATING INSTRUCTIONS

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE



**NOTE! Maximum torque 10 Nm (7.4 ft-lb). Excessive use of force may result in personal injury or the tool breaking!**

1. Wrap the wire around the liner



2. Hook up the wire as shown



# OPERATING INSTRUCTIONS

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE



**NOTE! Maximum torque 10 Nm (7.4 ft-lb). Excessive use of force may result in personal injury or the tool breaking!**

3. Tighten to maximum of 10 Nm either by hand or electric drill. Try to keep the tool perpendicular to the liner. Re-align the tool if necessary.

**NOTE! Twisting the tool when it is tightened might cause a puncture to the liner.**

**NOTE! Electric drill torque setting is not always accurate!**



# WARRANTY POLICY & PROCEDURE

## SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

### Limited Warranty:

Picote warrants to the original End User that the Product purchased by such End User will operate in accordance with, and substantially conform to their published specifications when shipped or otherwise delivered to the End User and for a period of one (1) year, except electric motors and batteries for which the warranty period shall be six (6) months, provided, however, that Picote does not warrant any claim or damage under this Warranty if such claim or damage results from:

1. Consumable parts or normal wear and tear resulting from use of the Products,
2. Product overload or overheated motor,
3. Regular periodic maintenance of Products,
4. Misuse, neglect, or improper installation or maintenance of the Products, or use of Products not for their intended purpose,
5. Products that have been altered, modified, repaired, opened or tampered with by anyone other than Picote or an authorized Picote Service Centre, or unsuitable or unauthorized spare parts, accessories or third party products when using the Products or;
6. the use of the Products not in compliance with their respective Documentation, user manuals, safety and maintenance instructions, and any usage restrictions contained therein, or
7. accident, fire, power failure, power surge, or other hazard.

Otherwise, the Products are sold AS IS. End User is responsible for using the Products within their specifications and instructions as contained in the Documentation.


**EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON INFRINGEMENT, SATISFACTORY QUALITY OR ARISING FROM A COURSE OF DEALING, LAW, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE EXTENT ALLOWED BY APPLICABLE LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO THE WARRANTY PERIOD. BECAUSE SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, THE ABOVE LIMITATION MAY NOT APPLY. This disclaimer and exclusion shall apply even if the express warranty set forth above fails of its essential purpose.**



**Please Contact:**

Your Reseller / Salesperson or Picote

[www.picotesolutions.com](http://www.picotesolutions.com)



**International Offices**

Finland. United Kingdom. USA.

**Technical Support**

[support@picotesolutions.com](mailto:support@picotesolutions.com)

**Claims**

[claims@picotesolutions.com](mailto:claims@picotesolutions.com)

**Production & R&D**

Pienteollisuustie 24  
06450 Porvoo, Finland  
[support@picotesolutions.com](mailto:support@picotesolutions.com)

**Authorised Resellers:**

[www.picotegroup.com/resellers](http://www.picotegroup.com/resellers)